

TOYOTA TACOMA (2016-2023)

A-PILLAR MOUNTING KIT





WHAT'S INCLUDED

- 2x A Pillar Mounting Brackets
- Fixtures
- Fitting Instructions

TOOLS REQUIRED

- Ratchet
- 12mm Socket

COMPATIBLE WITH LAMPS:

- RP Series
- Utility-25
- Utility-50
- ST2 Evolution

DIFFICULTY - 2/5



PRE-INSTALLATION CHECKS

1. Ensure all vehicle systems are fully operational prior to install, and directly afterwards.
2. Ensure battery is disconnected.

MOUNTING BRACKET INSTALLATION

RP Series shown for illustration purposes.

NOTE: If mounting any Utility-25 and ST-2 you may need a bigger washer that isn't included.



1. Tape off the area you'll be working in to protect the paint and prevent scratches.
2. Starting on the driver side, use a ratchet with a 12mm socket to remove the front bolt securing the hood to the hinge. Loosen the rear bolt, but do not remove it.
3. Position the driver-side bracket over the hood hinge, aligning the front mounting hole. The rear of the bracket should angle away to allow access to the rear bolt. Insert the front bolt through the bracket and thread it into the hood a few turns to hold the bracket loosely in place.

Tip: Mark the outline of the hood hinge before removal to help with realignment during reinstallation.

4. While supporting the hood, remove the rear bolt. Insert it through the rear hole of the bracket and thread it back into the hood. Align the hood hinge with the paint outline from its original position, then tighten both bolts securely.
5. Install Triple-R LED light.
6. Repeat steps on the other side of vehicle.
7. Run wiring to desired switch. It is recommended to use the available corresponding Triple-R wiring kit for your product (please refer to the wiring kit product page for further wiring instructions).