WARRANTY INFORMATION

Your purchase of this Triple-R Lights product is an investment in a product designed and manufactured to the highest standards, but sometimes things can go wrong. You do not need to register your product with us, as we can trace the product through the unique serial number of the lamp.

In the unlikely event of having to make a claim, please retain your purchase receipt and pass it back to the retailer from where you first purchased the product, at the point of raising any issue.

We hope you enjoy your Triple-R Lights product, and wish you many years of a safer, more enjoyable night driving experience.

THANK YOU!

We appreciate your purchase of a Triple-R Lights product, and value your feedback. If you would like to leave feedback on your Triple-R Lights experience, please head to the relevant product page on our website www.triple-r-lights.com.

LR-1000 WITH BEACON
# INSTRUCTIONS

MOUNTING OPTIONS

SIDE MOUNTING

It is advised to use an anti-seize compound or thread-lock when mounting from the side of the lamp(s).

CENTER MOUNTING

Tighten the M5 grub screws with the included allen key when bracket is positioned in the optimum position to suit the vehicle mounting points.

OR

ELECTRICAL INFORMATION

IMPORTANT - Please disconnect the vehicle battery before installing or servicing your LED light installation.
If in doubt, it is recommended to use the services of a professional installer.

It is recommended to use the available corresponding Triple-R wiring kit for your product. If utilizing existing (non Triple-R) wiring, make sure to use appropriate wire gauge and fusing in line with your lights technical specification.

WITH BACKLIGHT AND BEACON (6-PIN) | Example shown: LR-1000 WITH BEACON

Please note: LED lights are compatible with 10-32V, albeit Triple-R wiring kits come supplied with 12V relay as standard.

MOMENTARY SWITCH (OPTIONAL)
Adding a momentary switch will allow you to easily change the Beacon light pattern (16 flash patterns)..

ON/OFF BEACON SWITCH

87
86
85
30
RELAY

IGNITION — Customer's have the option to connect to a positive battery or ignition feed. Connecting to the ignition feed, the light will only operate with the ignition turned on.

GROUND

ON/OFF HIGH BEAM SWITCH

POSITIVE — **FUSE**

2-PIN SWITCH (OPTIONAL)
For connecting a single color backlight (white or amber).

IGNITION

3-PIN SWITCH (OPTIONAL)
For connecting and switching between both white and amber color backlight.

IGNITION

Connecting direct to the ignition means the backlight function will operate when the vehicle ignition is turned on.

1. **RED WIRE** - POSITIVE
2. **BLACK WIRE** - NEGATIVE
3. **BROWN WIRE** - AMBER BACKLIGHT
4. **GREEN WIRE** - WHITE BACKLIGHT
5. **GREY WIRE** - SYNC & FLASH POWER
6. **YELLOW WIRE** - BEACON POWER