

ACCESSORIES



BESPOKE VEHICLE INTEGRATION KITS



LAMP MOUNTING BRACKETS



UNIVERSAL MOUNTING KITS



DIFFUSER AND CLEAR LENSES



LENS COVERS



AMBER LENSES



WIRING KITS

WARRANTY INFORMATION

Your purchase of this Triple-R Lights product is an investment in a product designed and manufactured to the highest standards, but sometimes things can go wrong. You do not need to register your product with us, as we can trace the product through the unique serial number of the lamp.

In the unlikely event of having to make a claim, please retain your purchase receipt and pass it back to the retailer from where you first purchased the product, at the point of raising any issue.

We hope you enjoy your Triple-R Lights product, and wish you many years of a safer, more enjoyable night driving experience.

TRIPLE-R
HIGH PERFORMANCE LIGHTING

ELITE+

INSTRUCTIONS

TRIPLE-R
HIGH PERFORMANCE LIGHTING

WWW.TRIPLE-R-LIGHTS.COM


We appreciate your purchase of a Triple-R Lights product, and value your feedback. If you would like to leave feedback on your Triple-R experience, please head to the relevant product page on our website www.triple-r-lights.com.

+1 520 468 2633
sales@triple-r-lights.com

Triple-R Lights LLC, 600 North Bullard Avenue, Suite 6
Goodyear, Arizona, 85338, USA


 UK BUILT | US DRIVEN    /TRIPLERLIGHTS

MOUNTING OPTIONS




SIDE MOUNTING

It is advised to use an anti-seize compound or thread-lock when mounting from the side of the lamp(s).



CENTER MOUNTING

Tighten the M5 grub screws when bracket is positioned in the optimum position to suit the vehicle mounting points.



ELECTRICAL CONNECTION

IMPORTANT INFORMATION

Please disconnect the vehicle battery before installing or servicing your LED light installation. If in doubt, it is recommended to use the services of a professional installer.

It is recommended to use the available corresponding Triple-R wiring kit for your product. If utilizing existing (non Triple-R) wiring, make sure to use the appropriate wire gauge and fusing in line with your lights.

FUNCTIONS


The Elite+ LED light bars can operate in 4 different lighting modes, with internal memory to recall the last selected mode:

- **BOOST**
(white LED's only)
- **COMBO**
(white + yellow LED's)
- **SNOW/FOG/DUST MODE**
(yellow LED's only)
- **LOW OUTPUT MODE**
(white LED's only)

The different functions are selected by applying power to the corresponding Light Mode Selection wire on each lamp.

It is recommended to install a momentary switch to facilitate selection of each different mode. Depressing such a switch for 2 seconds will cause the light to immediately activate the Low Output Mode.

SUPERSEAL (3-PIN) / APTIV (3-PIN) | LINEAR-6 ELITE+ & LINEAR-18 ELITE+



ECONOSEAL (2-PIN) / APTIV (2-PIN) + SUPERSEAL (3-PIN) | LR-1250 ELITE+ & LR-24 ELITE+

